

**Fig. /Abb. 1**

# Gerad - Verzahnung

● Vor Demontage des Ankers  
 Kohlebürsten 5mm zurückziehen !  
 Before the armature is removed the carbon brushes must be withdrawn by at least 5mm !

